

Compass Calibration

1. Remove cover from compass (Phillips-head screw driver required). Press and hold CALIBRATE button for 5 seconds or until the CALIBRATE indicator LED begins to blink. Refer to picture below to locate CALIBRATE button.
2. While the CALIBRATE LED continues to flash rotate the vessel through a 720 degree turn. (Two complete revolutions) Minimum time per revolution is 1 minute.
3. After two complete revolutions, press and hold CALIBRATE button until indicator stops blinking. Calibration is now complete.
4. Replace cover. Use this procedure to recalibrate compass at any time.

CALIBRATE
button
Green calibrate
LED ¼" above to
the left

